

SAFETY FIRST



Read instructions



Wear safety glasses



Wear safety gloves

- ⚠ Read instructions.
- ⚠ Ensure Health and Safety, local authority and general workshop practice regulations are adhered to.
- ⚠ Ensure vehicle is correctly supported with road wheels secured, in line with manufactures guidelines.
- ⚠ Keep hands away from moving parts.
- ⚠ Wear safety gloves.
- ⚠ Wear safety glasses.
- ⚠ Wear suitable clothing to avoid snagging. Do not wear jewellery and tie back long hair.
- ⚠ Technical information available from www.bailcast.com or scanning QR code.



TRILOBAL JOINT

- ✓ Clean outside of the old boot at the joint side, using a suitable cleaner.
 - ✓ Trim the old boot 10-15mm from the joint leaving the trilobal part of the boot in position ^(Fig 1). This creates an exact fit adaptor that the new CV Boot can be attached to.
 - ✓ Remove the old clamps and boot leaving only the trilobal part in place on the joint.
 - ✓ Clean away any grease and debris from the shaft and joint.
- Installation Tip:** Do not use WD-40 or similar product to clean a CV joint, it will leave a residue when it dries that can negatively affect the new CV grease.
- ✓ Wipe the outside of the remaining trilobal part of the boot (all grease and debris should be removed to obtain a good seal).
 - ✓ Fit the new CV boot as detailed above, clamping the large end over the adaptor that has just been created.

